

**PEARL INVERTER HEAT PUMPS**

# THE INTELLIGENT SWIMMING POOL HEAT PUMP

*effortless heating solutions*

  
**BWT CONNECT**  
INSIDE



R32 Refrigerant



Quiet Operation



Full Inverter



-10°C Temp



25 Year Warranty\*



Pearl HPF

## Instructions Manual



BWT PEARL HPF 9  
BWT PEARL HPF 13  
BWT PEARL HPF 16  
BWT PEARL HPF 20  
BWT PEARL HPF 24  
BWT PEARL HPF 28

EN



### Declaration of conformity

Guidelines – Harmonised standards

### BWT Group

We hereby declare under our sole responsibility that this product complies with the relevant guidelines

**SAFETY** EN 60335-1:2012/A2:2019

EN 60335-2-40:2003/A13:2012

EN 62233:2008

**EMC** EN 55014-1:2017

EN 61000-3-11:2000

EN 55014-2:2015

EN 61000-3-3:2013

EN 61000-3-12:2011

EN 61000-3-2:2014

**NOISE** 200/14/CE

### HP Models:


BWT PEARL HPF 10/13/16/20/24/27

Other normative documents


Person authorised to manage technical documentation

**RoHS** 2011/65/EU

**WEEE** 2012/19/EU



### Processing by individuals of electronic appliances reaching the end of their lifespan:




The symbol depicting a barred wastebin that features on the main parts constituting the product indicates that it must not be discarded alongside household waste. It must be brought to an adequate collection point where electronic appliances are recycled (information available from your local waste treatment service). This product contains potentially hazardous substances.

### DELIVERY AND TRANSPORT

- When you have unpacked the HP, please check the content to report any damage. Please also check that the pressure reading on the pressure gauge corresponds to the outside temperature, as different values might indicate a leak, depending on the measured outdoor temperature, as different values might indicate a leak.
- The HP should always be stored and transported in a vertical position, on a pallet and inside its original packaging.
- Transporting and/or storing the HP horizontally will void the guarantee.

### DIMENSIONS



Models	A	B	C	D	E	F
BWT PEARL HPF 09	431 mm	1004 mm	612 mm	290 mm	189 mm	50 mm
BWT PEARL HPF 13	431 mm	1004 mm	612 mm	290 mm	189 mm	50 mm
BWT PEARL HPF 16	487 mm	1103 mm	719 mm	320 mm	199 mm	50 mm
BWT PEARL HPF 20	487 mm	1103 mm	719 mm	320 mm	199 mm	50 mm
BWT PEARL HPF 24	525 mm	1178 mm	869 mm	430 mm	234 mm	50 mm
BWT PEARL HPF 28	525 mm	1178 mm	869 mm	430 mm	234 mm	50 mm

**TECHNICAL SPECIFICATIONS**

Models	BWT PEARL HPF09	BWT PEARL HPF13	BWT PEARL HPF16	BWT PEARL HPF20	BWT PEARL HPF24	BWT PEARL HPF28
Recommended pool size	30-45 m <sup>3</sup>	55-70 m <sup>3</sup>	70-85 m <sup>3</sup>	85-105 m <sup>3</sup>	105-130 m <sup>3</sup>	130-160 m <sup>3</sup>
<b>Air 28°C / Water 28°C / 80%HR</b>						
Capacity in MAX Mode	9,3 kW	13,1 kW	16,1 kW	20,4 kW	24,2 kW	27,8 kW
COP MAX Mode	6,5 ~ 5,5	5,6	5,1	5,2	5,4	5,2
Capacity in ECO Mode	8,8 ~ 3,5 kW	13,1 ~ 4,2 kW	16,1 ~ 5,5 kW	20,4 ~ 6,5 kW	24,2 ~ 7,8 kW	27,8 ~ 10,5 kW
COP ECO Mode	10,8 ~ 5,5	11,2 ~ 5,6	10,8 ~ 5,1	10,1 ~ 5,2	10,8 ~ 5,4	10,1 ~ 5,2
Capacity in SILENT	5,8 ~ 3,5 kW	4,2 kW	5,5 kW	6,5 kW	7,8 kW	10,5 kW
COP SILENT	10,8 ~ 8,3	11,2	10,8	10,1	10,8	10,1
<b>Air 15°C / Water 26°C / 70%HR**</b>						
Capacity in MAX Mode	6,6 kW	9,8 kW	11,5 kW	14,8 kW	18,2 kW	22,8 kW
COP MAX Mode	5,3	4,7	4,4	4,5	4,4	4,2
Capacity in ECO Mode	6,6 ~ 3,2 kW	9,8 ~ 3,7 kW	11,5 ~ 4,2 Kw	14,8 ~ 4,9 kW	18,2 ~ 6,8 kW	22,8 ~ 8,1 kW
COP ECO Mode	6,7 ~ 5,6	7,0 ~ 4,7	6,7 ~ 4,4	6,6 ~ 4,5	6,7 ~ 4,4	6,5 ~ 4,2
Capacity in SILENT	3,8 ~ 3,2 kW	3,7 kW	4,2 kW	4,9 kW	6,8 kW	8,1kW
COP SILENT	6,7~5,6	7	6,7	6,6	6,7	6,5
Noise level mini-maxi (at 10m) according to EN ISO 3744:2010	21 ~ 25 dB(a)	23 ~ 28 dB(a)	25 ~ 30 dB(a)	25 ~ 30 dB(a)	26 ~ 31 dB(a)	26 ~ 32 dB(a)
Operating temperature	-15°C -> 38°C					
Compressor type	2D Technology Full DC 					
Expansion valve	Electronic					
Heat Exchanger	Optimal Twist					
Casing	ABS treated against UV					
Refrigerant	R32					
<b>Installation</b>						
Water connection	1,5" / 50 mm					
Power	230V / 1~N / 50 Hz					
Nominal current (Maximum Current)	6, 4, A (8, 8, A)	8,3 A (12,0 A)	11,5 A (15,3 A)	14,3 A (16A)	23,0 A (25,0 A)	28 A (30 A)
Max power input (Air 26°C)	1,1 kW	2,6 kW	2,9 kW	3,8 kW	4,2 kW	
Dimensions (L x l x h)	980 x 419 x 584		1080 x 479 x 707		1178 x 525 x 569	
Water flow	4 m <sup>3</sup> /h	4 m <sup>3</sup> /h	5 m <sup>3</sup> /h	6 m <sup>3</sup> /h	8 m <sup>3</sup> /h	10 m <sup>3</sup> /h
Water pressure drop	64 kPa		66 kPa		77 kPa	
Weight net (gross)	46 kg (54 kg)	48 kg (59 kg)	62 kg (72 kg)	63 kg (80 kg)	93 kg (111 kg)	94 kg (111 kg)

Installation (site, type of support, necessary space)	P. 19
Hydraulic connection	P. 20
Electrical connection	P. 20
Immersion and starting of HP	P. 22
Use	P. 22
Settings	P. 23
General use	P. 23
Regulation (Electronic controller)	P. 24
Mobile application : BWT Inverter	P. 25
Controller state table	P. 26
Maintenance	P. 27
Wintering	P. 27
Recycling the HP	P. 28
After-sales technical Departement	P. 28



This symbol indicates that the device uses R32, a coolant featuring a low combustion speed.



This symbol indicates that a maintenance technician must handle this equipment according to the operating manual.



This symbol indicates that the operating manual should be read attentively prior to use.

**WARNING: In normal conditions, a suitable HP can heat the water of the pool by 1°C to 2°C per day.**

It is therefore quite normal not to feel a temperature difference at the outlet of the circuit when the HP is operating. A heated pool should be covered to prevent heat losses. The appliance is designed to be used in a swimming pool as described in standard NF-EN-16713.

- Failure to comply with the warnings could cause damage to the swimming pool equipment as well as severe injuries or death.
- Only a qualified person possessing the adequate technical skills (electricity, hydraulic, refrigeration) is authorised to undertake maintenance operations or repairs on the device. A qualified technician working on the device must use/wear personal protective equipment (safety goggles, protection gloves, etc...) to avoid all risk of injury arising during work on the device.
- Prior to any intervention on the device, ensure that it is powered down and has undergone the lockout-tagout procedure.
- The device is designed specifically for use in swimming pools and spas; it must not be used for purposes other than the ones it was designed for.
- This device is not intended for children.
- This device is not intended to be used by persons (including children, of 8 or more) who lack experience or who suffer from physical, sensory, or mental impairment.

**Except:**

- if it is operated under supervision or with operating instructions issued by a person responsible for their safety; and
- if they understand the risks taken.
- Children must be supervised to ensure that they do not play with the device.
- The installation of the device should be carried out according to the manufacturer's instructions and in compliance with local and national applicable standards. The installer is responsible for the installation of the device and for compliance with national regulations relating to installation procedures. The manufacturer will not be liable in case of non-compliance with the installation standards that apply locally.
- For any action other than simple maintenance operations by the user as described in this manual, the product should be maintained by a certified professional.
- Any improper installation and/or use can cause damages and severe injuries (and even death).
- Do not touch the fan or the moving parts, and do not insert objects or your fingers close to the moving parts when the device is operating. ▪ Moving parts can cause severe injuries and even death.
- Do not pull on the hoses and the connections to move the machine.

**WARNINGS CONCERNING ELECTRICAL APPLIANCES:**

- The power supply of the device must be protected by a 30-mA security residual current protection system, as per the standards that apply in the country of installation.
- Do not use an extension to connect the device; only connect the device directly to a suitable power outlet.
- If a fixed device does not feature a power cord and a plug, or any other means to disconnect from the power supply with a separation of the contacts in all the poles, enabling total disconnection in case of a category III electrical surge, the manual will mention that the disconnection means must be integrated in the fixed wiring, as per relevant wiring rules.
- An adapted disconnection method, complying with all local and national requirements relating to category III electrical surges, and that disconnects all the poles of the supply circuit, must be installed in the supply circuit of the device. This disconnection method is not provided with the device and should be provided by the installation technician.
- Prior to installation, check that:
  - The voltage featuring on the information plate of the device matches the voltage of the power supply,
  - The power supply is suitable for operating the device and has an earthing connection.
  - The plug (as necessary) adapts to the plughole.
- If the power cord is damaged, it should imperatively be replaced by the manufacturer, a technician or a person qualified to ensure safety.

**WARNINGS RELATING TO DEVICES CONTAINING A COOLANT:**

- The coolant R32 is a coolant of category A2L, which is considered as potentially flammable.
- Do not release R32 fluid into the atmosphere. This fluid is a greenhouse effect fluorinated gas, covered by the Kyoto Protocol, with a global warming potential (GWP) = 675 for R32.
- The device must be stored in a well-ventilated place and kept away from flames.
- Install the unit outdoors. Do not install the unit indoors or in an outdoor area that is closed and poorly ventilated.
- To comply with the relevant standards and regulations in terms of the environment and installation procedures, and in particular with decree N° 2015-1790 and/ or European regulation EU 517/2014, a search for leaks of the cooling circuit must be conducted at least once a year. This operation should be carried out by a certified specialist of cooling devices.
- Please keep and transmit these documents for reference throughout the lifespan of the device.

## INSTALLATION (SITE, TYPE OF SUPPORT, NECESSARY SPACE)


- Install the HP outdoors at more than 2 meters from the pool.
- Place the HP on the provided vibration absorbers on a surface that is stable, solid (able to bear the weight of the device) and level (prepare a concrete base if necessary).
- Maintain 1 m (30 cm minimum) of open space in front of the vertical air intake grids (behind and on the side of the HP) and 3 m at the outlet of the fan (in front) of open space without any obstacles.
- Prepare sufficient space around the HP for maintenance operations.
- Prepare a water evacuation system close to the HP to protect the installation zone.
- Keep the HP out of the reach of children, insofar as possible.

The HP should never be installed:

- in an area covered by sprinkling systems, or subject to spray or running water or mud (close to a road, take into account the effects of wind),
- under a tree,
- close to a source of heat or of flammable gas,
- in an area where it would be exposed to oil, flammable gases, corrosive products, and compounds containing sulphur,
- close to equipment operating at high frequencies,
- in a place where snow is likely to accumulate,
- in a place where it could be flooded by the condensates produced by the device as it operates,
- on a surface that could transfer the vibrations to the house.

Advice: dampen the possible noise nuisance caused by your HP.

- Do not install it close to or underneath a window.
- Do not direct the outlet of the fan towards your neighbours' property.
- Do not direct the fan outlet (cold air) towards the swimming pool.
- Install it in an open area (sound waves bounce off surfaces).
- Install a sound barrier around the HP, making sure to maintain the required distances.
- Install 50 cm of PVC piping at the water inlet and outlet of the HP.



The HP must be installed and maintained on a fixed and solid basis, with the skids placed under the feet.


- For concrete, use adapted  $\varnothing$  8 mm lag screws fitted with washers to prevent any loosening.
- For wood, use adapted  $\varnothing$  8 mm hexagon head screws fitted with locking washers to prevent any loosening

## HYDRAULIC CONNECTION

- Water quality necessary for this device: NF-EN-16713-3
- The HP is compatible with all types of water treatment. The HP must imperatively be connected by a PVC pipe of Ø 50mm to the swimming pool's hydraulic circuit, after the filter and before the treatment system, regardless of its type (Cl, pH, Br metering pumps and/or electrolyser).
- Follow the hydraulic connection order (blue = water in, red = water out)
- A bypass must be installed to facilitate work on the HP.
- Before connecting the PVC pipes to the HP, make sure the circuit is clean of any work residue (stone, soil, etc.).

Connection of the condensate evacuation pack:

During operations, the HP is subject to a condensation phenomenon. This translates into a water flow, which can be more or less important depending on the degree of humidity. To channel this flow, which can represent several litres of water per day, we recommend you install the provided condensate evacuation pack and connect it to a suitable water evacuation circuit.



## ELECTRICAL CONNECTION

### Connection of the power supply:

prior to undertaking any intervention inside the HP, it is imperative to disconnect the power supply from the HP; there is a risk of electrocution that can cause damages, severe injuries and even death.

- Only a certified and experienced technician is authorised to conduct cabling work in an HP or to replace the power cable.
- the power supply should match the voltage featuring on the information plate of the HP.
- The HP must be connected to an earthing connection.

### Electrical Installation:

To ensure safe operations and to protect the integrity of your electric installation, the HP should be connected to the electrical mains according to the following rules:

- Upstream, the electrical mains should be protected by a 30-mA differential switch.
- The HP should be connected to a suitable class C circuit-breaker (see the table below) according to the standards and regulations in force in the country where the system is installed.
- It is recommended to crimp the electric cables on lugs adapted to the diameter of the cable chosen before connecting them to the HP
- The power cord should be adapted to the power of the HP and the length of cable required for the installation (see the table below). The cable must be suitable for outdoor use.
- In the case of a three-phase system, it is imperative to follow the connection order of the phases. If phases are inverted, the compressor of the HP will not work.
- In public spaces, the installation of an emergency stop button close to the HP is mandatory. The voltage must match the voltage mentioned on the HP.

The connections must be sized based on the power of the HP and on the installation state.

Model	Breaker		Maximum cable* length with cable sections:			
	Rated current (A)	Rated residual action current (mA)	2,5 mm <sup>2</sup>	4 mm <sup>2</sup>	6 mm <sup>2</sup>	10 mm <sup>2</sup>
BWT PEARL HPF 09/ 13	16 A	30 mA	24 m	39 m	56 m	96 m
BWT PEARL HPF 16/20	20 A	30 mA	19 m	30 m	44 m	75 m
BWT PEARL HPF 24	25 A	30 mA	-	23	32	56
BWT PEARL HPF 28	32 A	30 mA	-	-	28	48

 \*Maximum cable length between heat pump and head of line protection (C curve current protection)

It is recommended to use wire terminal for better electrical contact between wire and power supply terminal.

These data are only indicative, you must ask an electrician to determine the exact data for your pool installation.

Power supply must be equipped with grounding and 30 mA differential protection.

- Use the cable-gland and the pass-through provided inside the HP for the passage of the cable.
- As this heat pump is installed outdoors, it is mandatory to pass the cable through a protective sheath for this purpose. The power supply of the HP must be fitted with a protection device in accordance with the legislation in force.
- The electric cables must be buried at a depth of 50 cm (85 cm under a road or a path) in an electrical sheath (red corrugated). When a cable buried in a sheath crosses another cable or a pipe (gas, water, etc.) the distance between them must be greater than 20 cm.



- L** : Line
- N** : Neutral
- GND** : Ground
- P1** : Filtration pump relay neutral (option)
- P2** : Filtration pump relay line (option)

### Automation

You have a very low voltage terminal block to which you can connect your home automation. This is an ON / OFF dry contact. Remove the existing bridge. When your home automation opens this contact, the machine stops and displays the message: No flow.




## Heating priority (Option):

The filtration pump can be connected to the HP to force the filtration to operate if the water is not at the desired temperature. Prior to this connection, a "dry contact" (normally open relay or connector) with a 230V AC coil should be provided.

Electrical connections:

- Connect the coil of this relay (A1 and A2) on the P1 and P2 terminals of the HP.
- Connect the input and the output of the dry contact (normally open) in parallel with the dry contact of the filtration clock of the swimming pool.



**Parameter for taking the connection into account:** Check that the setting of the filtration pump parameter (parameter #9) is set to "2". If this is not the case, please contact us to change the setting.

## IMMERSION AND STARTING OF HP

Once the HP is connected to the water circuit with the bypass, and is connected to the power supply by a professional, ensure that:

- The HP is horizontal (level).
- The HP is secured and stable.
- The water circuit has been purged of air that has been trapped in the piping of the HP.
- The pressure gauge, at the back of the HP, shows a temperature that is equal to the ambient outdoor temperature.
- The water circuit is properly connected (no leaks or damage to the hydraulic connections, the connections are properly tightened).
- The electric circuit is properly connected (the cables are tightly secured to the terminals and intermediate circuit-breaker), properly insulated, and connected to the earthing connection.
- The conditions of installation and use described above have all been met.
- The outdoor temperature is between 0 and +35°C.
- The water temperature is of 15°C minimum.
- The evaporator at the rear/on the sides of the HP is clean (leaves, dust, pollen, cobwebs...)

You can now start your device by following, in the given order, the following steps:

- Open the 3 valves of the bypass (refer to the hydraulic diagram).
- Half-close the bypass valve.
- Remove all unused items or tools from the area surrounding the HP.
- Start the pump of the filtration system.
- Power up the HP by engaging the circuit-breaker and using the ON/OFF button of the display.
- Check that the HP starts and stops in sync with the filtration circuit: if no water is detected in the HP, the display shows "FLO"
- The HP starts after a delay of a few minutes.
- Adjust the temperature ("Regulation" chapter).
- Adjust the water flow ("Water flow setting" chapter).
- After a few minutes, you can adjust the bypass valve as indicated in the "Water flow setting" chapter. Having completed the above steps, cover the pool and let the HP operate for a few days with the filtration pump in "forced mode" until the water of the pool reaches the desired bathing temperature.

## USE

- Cover the pool with a cover (bubble cover, shutter...) to reduce heat losses.

**Water flow setting:**

- To optimise the heating performance and achieve power savings, the flow of water travelling through the HP should be adjusted.
- The adjustment is done based on the reading of the adjustment pressure gauge. The adjustment is done by opening or closing the adjustment valve of the bypass.
- To increase the pressure on the front pressure gauge: reduce the amount of water passing through the HP: open the bypass adjustment valve.
- To reduce the pressure on the front pressure gauge: increase the amount of water passing through the HP: close the bypass adjustment valve.
- During normal operations, the inlet and outlet valves must remain fully open.

**Normal pressure:**

- The flow of water through the HP and the fluid pressure in the device are intimately linked.
- The flow value given for information purposes is of 5 to 7m<sup>3</sup>/h, i.e. approximately 100l/min to reach the maximum heating power of the HP.
- The ideal setting is achieved when the hand of the pressure gauge (for heating operations in MAX mode) indicates a temperature in °C greater by 10 to 15°C than the current temperature of the swimming pool.
- Remember, the HP must operate for a few minutes before the pressure stabilises on the pressure gauge.
- Example: the swimming pool water is 20°C, the HP has been operating for 5 minutes, and the hand of the pressure gauge indicates 20 bars / 280 PSI / 32°C / 90°F. -> 32°C - 20°C = 12°C -> the setting is right (between 10 and 15°C).

**Abnormal pressure:**

- If the pressure at the pressure gauge is too high or too low, that means that the flow of water through the HP is inadequate.
- Action must therefore be taken by opening or closing progressively the bypass adjustment valve, to get the pressure in the recommended range.
- When stopped, the temperature reading should be close to the temperature of the swimming pool water.
- If the hand shows 0, the device should not be used (contact your distributor).

**Setting frequency:**

- The flow through the HP depends much on water temperature, and to a lesser extent, on air temperature. It should therefore be adjusted:
  - When the pump is started, and the water is cold;
  - During the rise of temperature;
  - When the desired temperature has been reached.

There should not be any reason to subsequently adjust the flow. An occasional reading of the pressure gauge to ensure everything is operating normally and the flow remains unchanged is generally sufficient.

## GENERAL USE

**Water quality (standard):**

Les standards de qualité de l'eau recommandés doivent absolument respecter les normes suivantes :

- Chlorine concentration less than 2.5 ppm
- pH between 6.9 and 8
- In case of sudden chlorination, isolate the heat pump by shutting the inlet and outlet valves of the device, and reset them to their initial positions after treatment.

**Maintaining the temperature:**

- Once the desired temperature has been reached, you can set the daily filtration time according to your habits (8 to 10 hours per day minimum during the season).

The heat pump will start automatically whenever necessary. The minimum operating time varies based on the time of use, please contact your distributor for further information.


If you notice the water temperature of the pool is falling, despite the device operating continuously, increase the daily filtration time.

Do not forget to cover the pool with an insulated cover when you are not using it, to limit heat losses.

**IMPORTANT: a swimming pool without a cover will lose 4 times more energy than the same pool with a cover.**

The choice of the heat pump should always take into account the presence of a tarpaulin, a rolling shutter, or any other type of protection of the pool when it is not being used.

**REGULATION (ELECTRONIC CONTROLLER)**



This model is equipped with BWT Inverter module allowing the user to control remotely the heat pump and its accessories with **BWT Inverter application**.

BWT Inverter will also allow you to communicate easily with our after sales technicians to solve remotely and quickly some of the machine disfuncions.

### The module position in the HP

The module is located on the side of the machine with the electrical connection blocks.




### Download the App

On apple or android store download the app, thanks to the Qr code located behind the electrical supply access hatch or below the nameplate of the machine.

#### Behind the access hatch



#### Near the nameplate



**CONTROLLER STATE TABLE**

Affichage	Explanation	Check	Solution (if no reset)
St-by	Stand-by		
FLO	No water flow or the flow switch doesn't detect the water flow	<ul style="list-style-type: none"> <li>- Check if filtration pump is working.</li> <li>- Check by-pass setting.</li> <li>- Check water flow switch position.</li> </ul>	Contact your seller
AL10 / AL11	HP error		
AL15 / AL16	Too much temperature difference between water in and water out.		
AL18	Comp. Out temp. Too high		
AL17	Low temp protection in cooling mode		
AL7 / AL8	Communication error	Check electrical connection between controller and electronic card inside the machine.	
AL3	Probe error (Water in)	Check probe connection.	
AL4	Probe error (Water out)		
AL5	Probe error (coil.)		
AL1	Probe error (comp. out)		
AL2	Probe error (comp. in)		
AL6	Probe error (ambiance)		
AL9	Fan error	Check fan connection.	
AL14	Outdoor temperature too low	Outdoor temp is below -15°C	Wait for the outdoor temperature to increase.
AL19 / AL20	Power supply problem	Ask an electrician specialist to check power supply.	Contact your seller
AL21 / AL22 / AL23 / AL24 / AL25	Electronic/overheating protection	Stop the power supply for 5 to 10 minutes, check that air flow is not blocked, turn ON power supply	

Before any maintenance operation, the heat pump must be completely stopped for few minutes before connecting pressure controllers. This is because high pressure and temperature inside the heat pump could be harmful.

Please check the following on a monthly basis:


- Check and clean the evaporator (with a soft brush or water jet).
- Do not use high pressure cleaner.
- Check all electrical and ground connections.
- Check that all electrical connections and terminals are securely connected.
- Check gas pressure (when heat pump is stopped, manometer must indicate a pressure higher than 0.5)

Please check the following points yearly:




- Check settings.
- Check securities.
- Check all electrical connections and ground.
- Check condenser cleanliness.
- Use soft soap and water to clean the heat pump casing, do not use solvents.

## WINTERING

1. Turn off the power supply to the HP
2. Fully open the bypass valve and close the HP inlet and outlet valves.



1. Unscrew the junctions to evacuate all the water contained in the HP.
2. Reconnect and slightly tighten the junctions by hand to prevent the introduction of foreign objects into the HP
3. Place the provided wintering blanket over the HP



## RECYCLING THE HP

When your HP reaches the end of its lifespan and you do not wish to keep it, do not throw it out with household waste.

The HP must be brought to a selective recycling point for its reuse or recycling.

It contains potentially hazardous substances that may harm the environment and that must, during recycling, be eliminated or neutralised.



- Bring the HP to a recycling center
- Give the HP to a not-for-profit organisation so that it can be repaired and reused
- Give the HP to the shop when buying a new unit

## AFTER-SALES TECHNICAL DEPARTEMENT

In case of technical problems regarding any of the BWT heat pumps, the following measures should be taken:

- Provide to the technical service the following essential information:
- Serial number of the machine
- Manometer value when machine is stopped
- Manometer value when machine is working
- The position of ON/OFF button and if it is lit or not
- The value and pictograms displayed on digital controller.
- The value of programmed settings
- If fan is working or not
- Position of the by-pass valves
- Contact your dealer and pass on this information together with the dimensions of the swimming pool, your personal details (address, telephone number) and the description of the failure.

If this procedure is respected, the BWT technician will be able to make as accurate diagnostic of the failure.

The recommended solution made by BWT will be implemented briefly after that.

**IMPORTANT: If this measure is not followed, warranty will be cancelled.**

Hotline Australia :           03 9580 9016



Pearl HPT

## Instructions Manual



BWT PEARL HPT 09  
BWT PEARL HPT 15  
BWT PEARL HPT 20

EN



### Declaration of conformity

Guidelines – Harmonised standards

#### BWT Group

We hereby declare under our sole responsibility that this product complies with the relevant guidelines

#### SAA:

**SAFETY** EN 60335-1:2012/A2:2019

EN 60335-2-40:2003/A13:2012

EN 62233:2008

**EMC** EN 55014-1:2017

EN 61000-3-11:2000

EN 55014-2:2015

EN 61000-3-3:2013

EN 61000-3-12:2011

EN 61000-3-2:2014

**NOISE** 200/14/CE

#### HP Models:

BWT Pearl HPT 09/12/15/18/20

Other normative documents

Person authorised to manage technical documentation


**RoHS** 2011/65/EU

**WEEE** 2012/19/EU



R&D Department  
France, 04/2022

### Processing by individuals of electronic appliances reaching the end of their lifespan:




The symbol depicting a barred wastebin that features on the main parts constituting the product indicates that it must not be discarded alongside household waste. It must be brought to an adequate collection point where electronic appliances are recycled (information available from your local waste treatment service). This product contains potentially hazardous substances.

### DELIVERY AND TRANSPORT

- When you have unpacked the HP, please check the content to report any damage. Please also check that the pressure reading on the pressure gauge corresponds to the outside temperature, as different values might indicate a leak, depending on the measured outdoor temperature, as different values might indicate a leak.
- The HP should always be stored and transported in a vertical position, on a pallet and inside its original packaging.
- Transporting and/or storing the HP horizontally will void the guarantee.

### DIMENSIONS



Models	A	B	C	D	E
All Models	704 mm	802 mm	177 mm	217 mm	243 mm

**TECHNICAL SPECIFICATIONS**

Models	BWT PEARL HPT09	BWT PEARL HPT15	BWT PEARL HPT20		
Recommended pool size	35-45 m <sup>3</sup>	55-70 m <sup>3</sup>	85-105 m <sup>3</sup>		
<b>Air 26°C / Water 26°C / 80%HR</b>					
Capacity in MAX Mode	9,5 kW	15,3 kW	20,1 kW		
COP MAX Mode	6,3	6,3	6,1		
Capacity in ECO Mode	9,5 ~ 3,2 kW	15,3 ~ 3,9 kW	20,1 ~ 5,5 kW		
COP ECO Mode	10,8 ~ 6,3	10,8 ~ 6,3	10,8 ~ 6,1		
Capacity in SILENT	3,2 kW	3,9 kW	5,5 kW		
COP SILENT	10,8	10,8	10,8		
<b>Air 15°C / Water 26°C / 70%HR**</b>					
Capacity in MAX Mode	6,9 kW	11,0 kW	14,5 kW		
COP MAX Mode	4,7	4,7	4,5		
Capacity in ECO Mode	6,9 ~ 3,5 kW	11,0 ~ 5,0 kW	14,5 ~ 7,0 Kw		
COP ECO Mode	6,6~4,7	7,7~4,7	7,9~4,5		
Capacity in SILENT	3,5 kW	5,0 kW	7,0 kW		
COP SILENT	6,4	6,5	6,6		
Noise level mini-maxi (at 10m) according to EN ISO 3744:2010	19 ~ 28 dB(a)	21 ~ 30 dB(a)	23 ~ 32 dB(a)		
Operating temperature	-10°C -> 38°C				
Compressor type	2D Technology Full DC 				
Expansion valve	Electronic				
Heat Exchanger	Optimal Twist				
Casing	ABS treated against UV				
Refrigerant	R32				
<b>Installation</b>					
Water connection	1,5" / 50 mm				
Power	230V / 1~N / 50 Hz				
Nominal current (Maximum Current)	6,0 A (9 A)	9,8 A (14,0 A)	14,2 A (17,0 A)		
Max power input (Air 26°C)	1,9 kW	2,9 kW	4,2 kW		
Dimensions (L x l x h)	Diameter 680 mm * height 775 mm				
Water flow	3 m <sup>3</sup> /h	5 m <sup>3</sup> /h	6 m <sup>3</sup> /h		
Water pressure drop	64 kPa				
Weight net (gross)	45 kg (65 kg)	49 kg (70kg)	59 kg (76 kg)		

Installation (site, type of support, necessary space)	P. 19
Hydraulic connection	P. 20
Electrical connection	P. 20
Immersion and starting of HP	P. 22
Use	P. 22
Settings	P. 23
General use	P. 23
Regulation (Electronic controller)	P. 24
Mobile application : BWT Inverter	P. 25
Controller state table	P. 26
Maintenance	P. 27
Wintering	P. 27
Recycling the HP	P. 28
After-sales technical Department	P. 28



This symbol indicates that the device uses R32, a coolant featuring a low combustion speed.



This symbol indicates that a maintenance technician must handle this equipment according to the operating manual.



This symbol indicates that the operating manual should be read attentively prior to use.

**WARNING: In normal conditions, a suitable HP can heat the water of the pool by 1°C to 2°C per day.**

It is therefore quite normal not to feel a temperature difference at the outlet of the circuit when the HP is operating. A heated pool should be covered to prevent heat losses.

The appliance is designed to be used in a swimming pool as described in standard NF-EN-16713.

- Failure to comply with the warnings could cause damage to the swimming pool equipment as well as severe injuries or death.
- Only a qualified person possessing the adequate technical skills (electricity, hydraulic, refrigeration) is authorised to undertake maintenance operations or repairs on the device. A qualified technician working on the device must use/wear personal protective equipment (safety goggles, protection gloves, etc...) to avoid all risk of injury arising during work on the device.
- Prior to any intervention on the device, ensure that it is powered down and has undergone the lockout-tagout procedure.
- The device is designed specifically for use in swimming pools and spas; it must not be used for purposes other than the ones it was designed for.
- This device is not intended for children.
- This device is not intended to be used by persons (including children, of 8 or more) who lack experience or who suffer from physical, sensory, or mental impairment.

**Except:**

- if it is operated under supervision or with operating instructions issued by a person responsible for their safety; and
- if they understand the risks taken.
- Children must be supervised to ensure that they do not play with the device.
- The installation of the device should be carried out according to the manufacturer's instructions and in compliance with local and national applicable standards. The installer is responsible for the installation of the device and for compliance with national regulations relating to installation procedures. The manufacturer will not be liable in case of non-compliance with the installation standards that apply locally.
- For any action other than simple maintenance operations by the user as described in this manual, the product should be maintained by a certified professional.
- Any improper installation and/or use can cause damages and severe injuries (and even death).
- Do not touch the fan or the moving parts, and do not insert objects or your fingers close to the moving parts when the device is operating. ▪ Moving parts can cause severe injuries and even death.
- Do not pull on the hoses and the connections to move the machine.

**WARNINGS CONCERNING ELECTRICAL APPLIANCES:**

- The power supply of the device must be protected by a 30-mA security residual current protection system, as per the standards that apply in the country of installation.
- Do not use an extension to connect the device; only connect the device directly to a suitable power outlet.
- If a fixed device does not feature a power cord and a plug, or any other means to disconnect from the power supply with a separation of the contacts in all the poles, enabling total disconnection in case of a category III electrical surge, the manual will mention that the disconnection means must be integrated in the fixed wiring, as per relevant wiring rules.
- An adapted disconnection method, complying with all local and national requirements relating to category III electrical surges, and that disconnects all the poles of the supply circuit, must be installed in the supply circuit of the device. This disconnection method is not provided with the device and should be provided by the installation technician.
- Prior to installation, check that:
  - The voltage featuring on the information plate of the device matches the voltage of the power supply,
  - The power supply is suitable for operating the device and has an earthing connection.
  - The plug (as necessary) adapts to the plughole.
- If the power cord is damaged, it should imperatively be replaced by the manufacturer, a technician or a person qualified to ensure safety.

**WARNINGS RELATING TO DEVICES CONTAINING A COOLANT:**

- The coolant R32 is a coolant of category A2L, which is considered as potentially flammable.
- Do not release R32 fluid into the atmosphere. This fluid is a greenhouse effect fluorinated gas, covered by the Kyoto Protocol, with a global warming potential (GWP) = 675 for R32.
- The device must be stored in a well-ventilated place and kept away from flames.
- Install the unit outdoors. Do not install the unit indoors or in an outdoor area that is closed and poorly ventilated.
- To comply with the relevant standards and regulations in terms of the environment and installation procedures, and in particular with decree N° 2015-1790 and/ or European regulation EU 517/2014, a search for leaks of the cooling circuit must be conducted at least once a year. This operation should be carried out by a certified specialist of cooling devices.
- Please keep and transmit these documents for reference throughout the lifespan of the device.

## INSTALLATION (SITE, TYPE OF SUPPORT, NECESSARY SPACE)


- Install the HP outdoors at more than 2 meters from the pool.
- Place the HP on the provided vibration absorbers on a surface that is stable, solid (able to bear the weight of the device) and level (prepare a concrete base if necessary).
- Maintain 1 m (30 cm minimum) of open space in front of the vertical air intake grids (behind and on the side of the HP) and 3 m at the outlet of the fan (on the top) of open space without any obstacles.
- Prepare sufficient space around the HP for maintenance operations.
- Prepare a water evacuation system close to the HP to protect the installation zone.
- Keep the HP out of the reach of children, insofar as possible.

The HP should never be installed:

- in an area covered by sprinkling systems, or subject to spray or running water or mud (close to a road, take into account the effects of wind),
- under a tree,
- close to a source of heat or of flammable gas,
- in an area where it would be exposed to oil, flammable gases, corrosive products, and compounds containing sulphur,
- close to equipment operating at high frequencies,
- in a place where snow is likely to accumulate,
- in a place where it could be flooded by the condensates produced by the device as it operates,
- on a surface that could transfer the vibrations to the house.

Advice: dampen the possible noise nuisance caused by your HP.

- Do not install it close to or underneath a window.
- Do not direct the outlet of the fan towards your neighbours' property.
- Do not direct the fan outlet (cold air) towards the swimming pool.
- Install it in an open area (sound waves bounce off surfaces).
- Install a sound barrier around the HP, making sure to maintain the required distances.
- Install 50 cm of PVC piping at the water inlet and outlet of the HP.



The HP must be installed and maintained on a fixed and solid basis, with the skids placed under the feet.

- For concrete, use adapted  $\varnothing$  8 mm lag screws fitted with washers to prevent any loosening.
- For wood, use adapted  $\varnothing$  8 mm hexagon head screws fitted with locking washers to prevent any loosening


The Ottimo HP has four feet and a condensate extraction nozzle included with the product. the condensate extraction nozzle and the four feet must be attached before installing the machine, using the described methode in the figure above.

## HYDRAULIC CONNECTION

- Water quality necessary for this device: NF-EN-16713-3
- The HP is compatible with all types of water treatment. The HP must imperatively be connected by a PVC pipe of Ø 50mm to the swimming pool's hydraulic circuit, after the filter and before the treatment system, regardless of its type (Cl, pH, Br metering pumps and/or electrolyser).
- Follow the hydraulic connection order (blue = water in, red = water out)
- A bypass must be installed to facilitate work on the HP.
- Before connecting the PVC pipes to the HP, make sure the circuit is clean of any work residue (stone, soil, etc.).

Connection of the condensate evacuation pack:

During operations, the HP is subject to a condensation phenomenon. This translates into a water flow, which can be more or less important depending on the degree of humidity. To channel this flow, which can represent several litres of water per day, we recommend you install the provided condensate evacuation pack and connect it to a suitable water evacuation circuit.



## ELECTRICAL CONNECTION

### Connection of the power supply:

prior to undertaking any intervention inside the HP, it is imperative to disconnect the power supply from the HP; there is a risk of electrocution that can cause damages, severe injuries and even death.

- Only a certified and experienced technician is authorised to conduct cabling work in an HP or to replace the power cable.
- the power supply should match the voltage featuring on the information plate of the HP.
- The HP must be connected to an earthing connection.

### Electrical Installation:

To ensure safe operations and to protect the integrity of your electric installation, the HP should be connected to the electrical mains according to the following rules:

- Upstream, the electrical mains should be protected by a 30-mA differential switch.
- The HP should be connected to a suitable class C circuit-breaker (see the table below) according to the standards and regulations in force in the country where the system is installed.
- It is recommended to crimp the electric cables on lugs adapted to the diameter of the cable chosen before connecting them to the HP
- The power cord should be adapted to the power of the HP and the length of cable required for the installation (see the table below). The cable must be suitable for outdoor use.
- In the case of a three-phase system, it is imperative to follow the connection order of the phases. If phases are inverted, the compressor of the HP will not work.
- In public spaces, the installation of an emergency stop button close to the HP is mandatory. The voltage must match the voltage mentioned on the HP.

The connections must be sized based on the power of the HP and on the installation state.

Model	Breaker		Maximum cable* length with cable sections:			
	Rated current (A)	Rated residual action current (mA)	2.5 mm <sup>2</sup>	4 mm <sup>2</sup>	6 mm <sup>2</sup>	10 mm <sup>2</sup>
BWT PEARL HPT 09	9 A	30 mA	43 m	68 m	100 m	170 m
BWT PEARL HPT 15	14 A	30 mA	24 m	39 m	56 m	96 m
BWT PEARL HPT 20	17 A	30 mA	19 m	30 m	44 m	75 m


 \*Maximum cable length between heat pump and head of line protection (C curve current protection)

It is recommended to use wire terminal for better electrical contact between wire and power supply terminal.

These data are only indicative, you must ask an electrician to determine the exact data for your pool installation.

Power supply must be equipped with grounding and 30 mA differential protection.

- Use the cable-gland and the pass-through provided inside the HP for the passage of the cable.
- As this heat pump is installed outdoors, it is mandatory to pass the cable through a protective sheath for this purpose. The power supply of the HP must be fitted with a protection device in accordance with the legislation in force.
- The electric cables must be buried at a depth of 50 cm (85 cm under a road or a path) in an electrical sheath (red corrugated). When a cable buried in a sheath crosses another cable or a pipe (gas, water, etc.) the distance between them must be greater than 20 cm.



### Automation

You have a very low voltage terminal block to which you can connect your home automation. This is an ON / OFF dry contact. Remove the existing bridge. When your home automation opens this contact, the machine stops and displays the message: No flow.




## Heating priority (Option):

The filtration pump can be connected to the HP to force the filtration to operate if the water is not at the desired temperature. Prior to this connection, a "dry contact" (normally open relay or connector) with a 230V AC coil should be provided.

Electrical connections:

- Connect the coil of this relay (A1 and A2) on the P1 and P2 terminals of the HP.
- Connect the input and the output of the dry contact (normally open) in parallel with the dry contact of the filtration clock of the swimming pool.



**Parameter for taking the connection into account:** Check that the setting of the filtration pump parameter (parameter #9) is set to "2". If this is not the case, please contact us to change the setting.

## IMMERSION AND STARTING OF HP

Once the HP is connected to the water circuit with the bypass, and is connected to the power supply by a professional, ensure that:

- The HP is horizontal (level).
- The HP is secured and stable.
- The water circuit has been purged of air that has been trapped in the piping of the HP.
- The pressure gauge, at the back of the HP, shows a temperature that is equal to the ambient outdoor temperature.
- The water circuit is properly connected (no leaks or damage to the hydraulic connections, the connections are properly tightened).
- The electric circuit is properly connected (the cables are tightly secured to the terminals and intermediate circuit-breaker), properly insulated, and connected to the earthing connection.
- The conditions of installation and use described above have all been met.
- The outdoor temperature is between 0 and +35°C.
- The water temperature is of 15°C minimum.
- The evaporator at the rear/on the sides of the HP is clean (leaves, dust, pollen, cobwebs...)

You can now start your device by following, in the given order, the following steps:

- Open the 3 valves of the bypass (refer to the hydraulic diagram).
- Half-close the bypass valve.
- Remove all unused items or tools from the area surrounding the HP.
- Start the pump of the filtration system.
- Power up the HP by engaging the circuit-breaker and using the ON/OFF button of the display.
- Check that the HP starts and stops in sync with the filtration circuit: if no water is detected in the HP, the display shows "FLO"
- The HP starts after a delay of a few minutes.
- Adjust the temperature ("Regulation" chapter).
- Adjust the water flow ("Water flow setting" chapter).
- After a few minutes, you can adjust the bypass valve as indicated in the "Water flow setting" chapter. Having completed the above steps, cover the pool and let the HP operate for a few days with the filtration pump in "forced mode" until the water of the pool reaches the desired bathing temperature.

## USE

- Cover the pool with a cover (bubble cover, shutter...) to reduce heat losses.

**Water flow setting:**

- To optimise the heating performance and achieve power savings, the flow of water travelling through the HP should be adjusted.
- The adjustment is done based on the reading of the adjustment pressure gauge. The adjustment is done by opening or closing the adjustment valve of the bypass.
- To increase the pressure on the front pressure gauge: reduce the amount of water passing through the HP: open the bypass adjustment valve.
- To reduce the pressure on the front pressure gauge: increase the amount of water passing through the HP: close the bypass adjustment valve.
- During normal operations, the inlet and outlet valves must remain fully open.

**Normal pressure:**

- The flow of water through the HP and the fluid pressure in the device are intimately linked.
- The flow value given for information purposes is of 5 to 7m<sup>3</sup>/h, i.e. approximately 100l/min to reach the maximum heating power of the HP.
- The ideal setting is achieved when the hand of the pressure gauge (for heating operations in MAX mode) indicates a temperature in °C greater by 10 to 15°C than the current temperature of the swimming pool.
- Remember, the HP must operate for a few minutes before the pressure stabilises on the pressure gauge.
- Example: the swimming pool water is 20°C, the HP has been operating for 5 minutes, and the hand of the pressure gauge indicates 20 bars / 280 PSI / 32°C / 90°F. -> 32°C - 20°C = 12°C -> the setting is right (between 10 and 15°C).

**Abnormal pressure:**

- If the pressure at the pressure gauge is too high or too low, that means that the flow of water through the HP is inadequate.
- Action must therefore be taken by opening or closing progressively the bypass adjustment valve, to get the pressure in the recommended range.
- When stopped, the temperature reading should be close to the temperature of the swimming pool water.
- If the hand shows 0, the device should not be used (contact your distributor).

**Setting frequency:**

- The flow through the HP depends much on water temperature, and to a lesser extent, on air temperature. It should therefore be adjusted:
  - When the pump is started, and the water is cold;
  - During the rise of temperature;
  - When the desired temperature has been reached.

There should not be any reason to subsequently adjust the flow. An occasional reading of the pressure gauge to ensure everything is operating normally and the flow remains unchanged is generally sufficient.

**Water quality (standard):**

Les standards de qualité de l'eau recommandés doivent absolument respecter les normes suivantes :

- Chlorine concentration less than 2.5 ppm
- pH between 6.9 and 8
- In case of sudden chlorination, isolate the heat pump by shutting the inlet and outlet valves of the device, and reset them to their initial positions after treatment.

**Maintaining the temperature:**

- Once the desired temperature has been reached, you can set the daily filtration time according to your habits (8 to 10 hours per day minimum during the season).


The heat pump will start automatically whenever necessary. The minimum operating time varies based on the time of use, please contact your distributor for further information.

If you notice the water temperature of the pool is falling, despite the device operating continuously, increase the daily filtration time.

Do not forget to cover the pool with an insulated cover when you are not using it, to limit heat losses.

**IMPORTANT: a swimming pool without a cover will lose 4 times more energy than the same pool with a cover.**

The choice of the heat pump should always take into account the presence of a tarpaulin, a rolling shutter, or any other type of protection of the pool when it is not being used.



This model is equipped with BWT Inverter module allowing the user to control remotely the heat pump and its accessories with **BWT Inverter application**.

BWT Inverter will also allow you to communicate easily with our after sales technicians to solve remotely and quickly some of the machine disfuncions.

### The module position in the HP

The module is located on the side of the machine with the electrical connection blocks.




### Download the App

On apple or android store download the app, thanks to the Qr code located behind the electrical supply access hatch or below the nameplate of the machine.

#### Behind the access hatch



#### Near the nameplate



**CONTROLLER STATE TABLE**

Affichage	Explanation	Check	Solution (if no reset)
St-by	Stand-by		
FLO	No water flow or the flow switch doesn't detect the water flow	<ul style="list-style-type: none"> <li>- Check if filtration pump is working.</li> <li>- Check by-pass setting.</li> <li>- Check water flow switch position.</li> </ul>	Contact your seller
AL10 / AL11	HP error		
AL15 / AL16	Too much temperature difference between water in and water out.		
AL18	Comp. Out temp. Too high		
AL17	Low temp protection in cooling mode		
AL7 / AL8	Communication error	Check electrical connection between controller and electronic card inside the machine.	
AL3	Probe error (Water in)	Check probe connection.	
AL4	Probe error (Water out)		
AL5	Probe error (coil.)		
AL1	Probe error (comp. out)		
AL2	Probe error (comp. in)		
AL6	Probe error (ambiance)		
AL9	Fan error	Check fan connection.	
AL14	Outdoor temperature too low	Outdoor temp is below -15°C	Wait for the outdoor temperature to increase.
AL19 / AL20	Power supply problem	Ask an electrician specialist to check power supply.	Contact your seller
AL21 / AL22 / AL23 / AL24 / AL25	Electronic/overheating protection	Stop the power supply for 5 to 10 minutes, check that air flow is not blocked, turn ON power supply	

Before any maintenance operation, the heat pump must be completely stopped for few minutes before connecting pressure controllers. This is because high pressure and temperature inside the heat pump could be harmful.

Please check the following on a monthly basis:


- Check and clean the evaporator (with a soft brush or water jet).
- Do not use high pressure cleaner.
- Check all electrical and ground connections.
- Check that all electrical connections and terminals are securely connected.
- Check gas pressure (when heat pump is stopped, manometer must indicate a pressure higher than 0.5)

Please check the following points yearly:




- Check settings.
- Check securities.
- Check all electrical connections and ground.
- Check condenser cleanliness.
- Use soft soap and water to clean the heat pump casing, do not use solvents.

## WINTERING

1. Turn off the power supply to the HP
2. Fully open the bypass valve and close the HP inlet and outlet valves.



1. Unscrew the junctions to evacuate all the water contained in the HP.
2. Reconnect and slightly tighten the junctions by hand to prevent the introduction of foreign objects into the HP
3. Place the provided wintering blanket over the HP



## RECYCLING THE HP

When your HP reaches the end of its lifespan and you do not wish to keep it, do not throw it out with household waste.

The HP must be brought to a selective recycling point for its reuse or recycling.

It contains potentially hazardous substances that may harm the environment and that must, during recycling, be eliminated or neutralised.



- Bring the HP to a recycling center
- Give the HP to a not-for-profit organisation so that it can be repaired and reused
- Give the HP to the shop when buying a new unit

## AFTER-SALES TECHNICAL DEPARTEMENT

In case of technical problems regarding any of the BWT heat pumps, the following measures should be taken:

- Provide to the technical service the following essential information:
- Serial number of the machine
- Manometer value when machine is stopped
- Manometer value when machine is working
- The position of ON/OFF button and if it is lit or not
- The value and pictograms displayed on digital controller.
- The value of programmed settings
- If fan is working or not
- Position of the by-pass valves
- Contact your dealer and pass on this information together with the dimensions of the swimming pool, your personal details (address, telephone number) and the description of the failure.

If this procedure is respected, the BWT technician will be able to make as accurate diagnostic of the failure.

The recommended solution made by BWT will be implemented briefly after that.

**IMPORTANT: If this measure is not followed, warranty will be cancelled.**

Hotline Australia : 03 9580 9016